

6.10.25

EXP : 14

Implementation of packets

Sniffing using RAW sockets

AIM:

To implement packet sniffing using RAW sockets.

Algorithm :

```

from scapy.all import sniff
from scapy.layers.net import IP, TCP, UDP,
def packet_callback(packet):
    if IP in packet:
        ip_layer = packet[IP]
        protocol = ip_layer.proto
        src_ip = ip_layer.src
        dest_ip = ip_layer.dst
        protocol_name = "Unknown"
        if protocol == 1:
            protocol_name = "ICMP"
        elif protocol == 6:
            protocol_name = "TCP"
        elif protocol == 17:
            protocol_name = "UDP"
        else:
            protocol_name = "Unknown protocol"
    
```

difference between user and socket API

```
print(f"Protocol : {protocol-name}")  
print(f"source IP : {src_ip}")  
print(f"Destination IP : {dest_ip}")  
print("-" * 50)  
sniff(iface='Wi-Fi', prn=packet_callback,  
      filter="ip", store=0)
```

Sample Input:

Step 1: Open a web browser and visit
https://www.google.com.

Step 2: Run the command 8.8.8.8 ping in
another terminal.

Sample Output:

Protocol : TCP

Source IP : 192.168.1.5

Destination IP : 192.250.188.110

RESULT:

Hence the experiment on the

implementation of packet sniffing using
RAW sockets has been executed successfully