

2/9/25, 03:30 pm

## PRACTICAL - 10 (a)

AIM:

Internetworking with routers in CPT simulator.

Design and configure a simple internetworking using a router.

In this network a router and 2 PCs are used. Computers are connected with routers using a copper straight through cable.

Procedure:

Step - 1 (Configuring Router 1):

1. Select the router and OPEN CLT
2. Press Enter to start Configuring Router 1

3. Type enable to activate the privileged mode.

Step - 2 (Configuring PCs):

1. Assign IP addresses to every PC in the network.
2. Go to desktop and select IP Config and IP address
3. Assign the default gateway of PC as 192.168.10.1

4) Assign the default gateway of PC1  
as 192.168.20.1

### Step - 3 (Connecting PCs with Router):

1. Connect Fast Ethernet (1) port of

PC0 with Fast Ethernet 0/0 port of  
R1 using Copper cable.


2. Similarly do the same for  
port of PC1.

### Router Configuration Table:


Device Name	IP address	Fast Eth 0/0	subnet mask	IP address	Fast Eth 0/1	subnet mask
Router1	192.168.10.1		255.255.255.0	192.168.20.1		255.255.255.0

### PC Configuration Table:

Device name	IP address	subnet mask	Gateway
PC0	192.168.10.2	255.255.255.0	192.168.20.1
PC1	192.168.20.2	255.255.255.0	192.168.20.1



naar deast drenthe



1668

三

*lab*

newspaper societies are organized

where we live will affect

spider eaten w/ raw

zusammenfassendes Schreiben ist ein  
zusammenfassendes Schreiben ist ein

22/9/25

## PRACTICAL-10(b)

AIM:

Design and configure internetwork using wireless router, DHCP server and internet Colad.

Part 1:

Build a simple network in the logical Topology workspace.

Step 1:

Launch Packet Tracer.

Step 2:

Build the Topology

- Add network devices to workspace
- Change display names of the network devices.
- Add the physical cabling between devices on the workplace.

Part 2:

Configure the Network devices.

Step 1:

Configure the wireless router

- Create the wireless network on the wireless router
- Configure the internet connection

on the wireless router, click setup tab in the wireless GUI.

b. Click on the Save Setting tab

Step 2: Configure the laptop

a. Configure the laptop to access the wireless network.

b. Click on the Desktop tab (at the top) and select the PC wireless icon

Step 3: Configure the PC

a. Configure the PC for the wired network

Step 4: Configure the Internet cloud

a. Install modules if necessary

b. Identify the from X to port

c. Identify the type of provider

Step 5: Configure the Cisco.com server

a. Configure the Cisco.com server as a DHCP server

b. Configure the Cisco.com server as

a DNS server to provide domain name to IPv4 address resolution

c. Configure the Cisco.com server global settings

Step 2: Configure the Cisco.com server Fast Ethernet (1) interface settings.

Part 3: Verify Connectivity

Step 1: Refresh the TELNET settings on the PC

- Verify that the PC is receiving IPv4 configuration information from DHCP.
- Test connectivity to Cisco.com server from the PC.

Student observation:

Question 1: What is a DHCP?

Key features of configuring a wireless router and DHCP server.

Answer:



- Wireless Router Configuration
- DHCP Server Configuration

Question 2: What is the significance of DHCP in internetworking?

- Elimination manual configuration
- Prevents IP address conflicts
- Enables scalability & mobility

Question 3 :

Design of Lab inter - network



Result :

thus the ~~inter~~ networking was performed successfully.